

32SA POP-UP GEAR DRIVEN ROTOR



Simple to use: Find your fixed LEFT edge.



Find your fixed LEFT edge.
Using the palm of your hand, turn
the center cap to the right until it
stops. Then turn it to the left until it
stops. This is your fixed left edge.



Adjusting the Pattern.

Arc is preset to rotate 180°.

Using a screwdriver, adjust the arc dial clockwise (+) to increase the arc or counterclockwise (-) to decrease the arc. Pattern is adjustable from 40° to 360°. Do not turn past right or left stop. Adjust wet or dry.



Adjusting the Radius.

Using a screwdriver, turn radiusreduction screw to reduce radius up to 35%. Adjust wet or dry.

up to 35%. Adjust wet or d					
	3.0 Pre-Installe	d Nozzle*	Perform	ance Cha	rt
	Pressure PSI	25	35	45	
	Radius ft.	29	31	31	ĺ
Į.	Flow GPM	2.17	2.60	3.00	Ī

*Rain Curtain[™] Nozzle Technology

for even water distribution

Questions? Please call 1-800-Rain Bird or visit us at www.rainbird.com

© 2002 Rain Bird Corporation